

HOW TO REPLACE THE CRANK GEAR ON A SHADE WITH A HOUSING BOX

- Remove set screws from bottom bar. Slip off eyelets to remove bottom bar from fabric pocket.
- Remove front cover from box by removing 1 hood screw from each side.
- Remove cradle idler bolt from non-operation side.
- Remove Roller Tube with fabric. 2 person job, pull roller shade out from idler end and slip off gear end.
- Remove bolts from the outside of end cap on gear side.
- Re-install new gear.
- Reinsert Roller shade and re-install idler bolt.
- Reinstall bottom bar and set screws.
- Operate shade a couple of times.
- Re-install front cover to complete.